

Windows 98, ME & 2000:

1. Extract the new driver and setup the Che-ez! Splash Explorer with the setup.exe that contained inside the file.
2. Power on the Splash camera and connect it to the computer.
3. "USB" will be showed on the display of the camera.
4. Right click the "My computer" icon on the desktop and choose properties from the popup menu.
5. Click device manager and search for image devices. You would find there is a device called WWL 102 Composite Device.
6. Double click to open it and choose Driver.
7. Click update driver and search for a better driver with the specified location: <location that you extracted the driver>\.
8. After updating, reboot the computer once.

Windows XP:

1. Extract the new driver and setup the Che-ez! Splash Explorer with the setup.exe that contained inside the file.
2. Power on the Splash camera and connect it to the computer.
3. "USB" will be showed on the display of the camera.
4. For Windows XP, there may be no "My computer" icon on the desktop. Please open the "Start" menu and right click the "My computer" icon from that menu.
5. Choose Hardware and click device manager.
6. Search for image devices. You would find there is a device called WWL 102 Composite Device.
7. Double click to open it and choose Driver.
8. Click update driver and search for a better driver with the specified location: <location that you extracted the driver>\.
9. After updating, reboot the computer once.